




OPERATING INSTRUCTIONS AND SERVICE MANUAL

OUTDOOR HOCKEY SCOREBOARD

MODEL MP-3524 With MP-3000 Control



EFFECTIVE S.N.XXXX, SEPT. 13, 1996

TABLE OF CONTENTS

1. GENERAL INFORMATION
 - 1.1 DESCRIPTION
 - 1.2 IDENTIFICATION
 - 1.3 DAMAGE
 - 1.4 DAMAGE CLAIM PROCEDURE
2. INSTALLATION
 - 2.1 GENERAL INFORMATION
 - 2.2 INSPECTION
 - 2.3 DATA CABLE INSTALLATION
 - 2.4 ELECTRICAL CONNECTIONS
3. CONTROL CONSOLE OPERATION
 - 3.1 SCOREBOARD POWER
 - 3.2 CONSOLE DISPLAY
 - 3.3 CONSOLE POWER
 - 3.4 TIME OF DAY TIMER
 - 3.5 TO USE SCOREBOARD
 - 3.6 TIME SETTING AND CONTROL
 - 3.7 TEAM SCORES
 - 3.8 HORN
 - 3.9 PERIOD INDICATORS
 - 3.10 TIMEOUT PERIOD
 - 3.11 PENALTY TIME CONTROL
 - 3.12 TIME OUTS LEFT
 - 3.13 SHOTS ON GOAL
 - 3.14 INTERVAL TIMER
4. MAINTENANCE AND TROUBLESHOOTING
 - 4.1 INTRODUCTION
 - 4.2 TEST EQUIPMENT
 - 4.3 TROUBLESHOOTING
 - 4.4 TROUBLESHOOTING GUIDE
5. REPLACEMENT PARTS LIST
 - 5.1 SCOREBOARD DISPLAY PARTS
 - 5.2 SCOREBOARD CONTROLLER ASSEMBLY PARTS
6. DIAGRAMS
 - 6.1 CONTROL CONSOLE KEYBOARD AND SLIPSHEET LAYOUT
 - 6.2 SCOREBOARD SYSTEM LAYOUT
 - 6.3 SINGLE WALL JUNCTION BOX WIRING DIAGRAM (C-12675-2)
 - 6.4 CONTROLLER PLATE WIRING AND LAYOUT (D-13202)
 - 6.5 POWER WIRING DIAGRAM
 - 6.6 MICROPROCESSOR 4 X 7 LAMP PATTERN (8 BIT)
 - 6.7 FIGUREGRAM WIRING DIAGRAM (C-150429)
 - 6.8 THREE POSITION DRIVER BOARD JUMPER LOCATION (B-151285)
 - 6.9 TRIAC PLACEMENT DIAGRAM
 - 6.10 INSTALLATION DRAWING

1. GENERAL INFORMATION

1.1 DESCRIPTION

Your All-American scoreboard has been carefully inspected and tested before leaving the factory. It is possible, however, that components may be loosened or forced out of adjustment in transit. If this occurs, follow the troubleshooting guide (section 4). If equipment then fails to operate, contact immediately:

ALL-AMERICAN Service Department
EVERBRITE LLC
P.O. Box 100
Pardeeville, WI 53954
Telephone: (608) 429-2121
Toll Free: 800-356-8146
E-mail: score@everbrite.com

Parts being returned for repair are to be sent to:

ALL-AMERICAN Service Department
EVERBRITE LLC
401 S. Main Street
Pardeeville, WI 53954

NOTE

If you need to send parts in for repair, please call the ALL AMERICAN service department for a returned goods authorization (RGA) number.

1.2 Identification

ALL-AMERICAN uses a 5 digit serial number for scoreboard identification. The serial number tags are located on the back of the control console and the lower right hand corner on the face of the scoreboard display. When contacting the factory for assistance it is important that the model number and serial number are known.

1.3 Damage

Upon receipt of equipment, check for visible damage. If this occurs, or if damage is found after shipment has been accepted, follow the damage claim procedure.

1.4 Damage Claim Procedure

An instruction sheet is enclosed advising the consignee in case of damage in transit.

If damage is noted at the time of delivery, consignee must obtain an 'Inspection of Bad Order'

from the delivering carrier. In order to process your claim, this must be properly filled out with a complete statement of all damage and it must be signed by the carrier.

If damage is discovered after delivery, you should call the delivery company. Have them make out a Concealed Damage Report. Fifteen days after delivery are allowed, so this should be done promptly or it is impossible to process this claim.

Advise EVERBRITE corporation of necessary replacement parts, or repairs. Consignee will be invoiced and then should file a claim with the carrier to recover charges. To file your claim follow this procedure:

- (A) Cost of replacement parts or repair charges are invoiced to the carrier by the consignee.
- (B) The following documents, properly filled out, plus invoice, are forwarded to the trucking company in support of your claim:
 - (a) Original bill of lading
 - (b) Original paid freight bill
 - (c) Certified copy of original invoice
 - (d) Standard form for presentation of loss and damage claim

2. INSTALLATION

2.1 General Information

Shipping papers accompany each scoreboard. Check carefully to see that you receive the following:

- 1 ea Hockey Display (2 Crates)
- 1 ea Control Console
- 1 ea Service Manual
- 1 ea Mounting Hardware Package
- 1 ea Press Box Junction Box
- 1 ea Trumpet Horn
- ? ft Control Cable (if ordered)

IMPORTANT!

The MP-40 cable supplied by ALL AMERICAN SCOREBOARDS for use on the Microprocessor based scoreboards is specifically designed for this system. Use of a substitute cable may void the warranty on the scoreboard!

2.2 Inspection

Inspect each unit and tighten all screws, lamps, and fittings that may have loosened in shipment.

2.3 Installation

Select the location best suited for visibility by the majority of spectators. Preferred position is facing east or north to avoid direct sunlight on the face of the scoreboard, if day games are played.

The MP-40 data cable carries only low voltage signals and therefore can be installed with or without conduit. consult section 6 for junction box and scoreboard wiring.

2.4 Electrical connections

This scoreboard requires a 120/240 VAC 100 AMP AC service for the exclusive use of the scoreboard.

NOTE

To protect the MP-3000 control from damage, it is advisable that you disconnect the control and store in a dry secure area when not in use.

NOTE

This equipment is **ETL** (Electronics Testing Laboratories) **CSA** and **NRTL** approved and complies with the requirements in part 15 of the FCC rules for a class A computing device. Operation of this equipment in a residential area may cause unacceptable interference to radio and television reception, requiring the operator to take whatever steps are necessary to correct the interference.

3. CONTROL CONSOLE OPERATION

3.1 Scoreboard Power

Turn on the branch circuits to the scoreboard. The Home and Guest scores will show "0".

3.2 Console Display

The 2 line by 20 character Liquid Crystal Display module displays the scoreboard information entered from the keyboard. The following information is displayed continuously: Time, Home and Guest scores, Period, Goal, Time Outs Left, Shots on Goal, Horn No., and Auto Horn Enable.

3.3 Console Power

Plug the control console cable into the wall junction box.

Push **ON/OFF** once to turn the console on.

Push **ON/OFF** a second time to shut the console off.

When first turned on; the console display should show as follows.

CLEAR 1=YES 2=NO

If a game is interrupted and you want to start from where you left off, answer **NO** and the control will restore the scoreboard as it was when last used.

If you are starting a new game, answer **YES**.

After answering yes or no; the console display should show as follows.

**ROLLER HOCKEY
MP-3524 VER 1.0 1996**

3.4 Time of Day Timer

To set the scoreboard for Time of Day; push

SET

The LCD display should read as follows:

TIME = 00

Push the keys for the current time, and then push

ENTER

The scoreboard will now display Time of Day. If desirable, you may disconnect the control console and put it away.

If at this time you want to use the scoreboard for a game, input the code and it will be set for the game. After the game, if you unplug the control, the scoreboard will again show the time of day.

3.5 To Use Scoreboard

Enter the two digit code (40) shown in the lower right corner of the keyboard as in the following example:

Push


CODE

4

0

ENTER

When the proper code has been entered, the timer on the scoreboard will show ":00", and the console display will show as follows.



3.6 Time Setting and Control

To set an 8 minute period, Push: **SET** **8** **0** **0** **ENTER** .

Any time up to 99:59 may be preset in a similar manner.

The **UP/DN** key determines the timer mode. When in the UP mode an arrow

up symbol is displayed next to the time on the LCD display. If in the DOWN mode there is no arrow displayed.

Switching the time toggle switch to the IN and OUT position, starts and stops the timer.

Push **RESET** to return the timer to the previously set value.

3.7 Team Scores

The Home and Guest Scores can be changed in three different ways.

(A) To add 1 to the existing score: Push **+1** .

(B) To directly enter or correct a score: Push Home or Guest **SCORE** followed by the desired number, then **ENTER** .

Example: Present Home Score is 15. Change the score from 15 to 23.

Push: Home **SCORE** **2** **3** **ENTER** .

(C) To clear the score: Push **SCORE** **CLEAR** .

3.8 Horn

Push: **HORN SEL** to select the horn to use.

The horn will blow for 1/2 second each time **HORN** is pressed.

The horn will blow automatically at the end of each period for 3 seconds.

The automatic horn function may be disabled by using the **AUTO HORN** key.

An 'H' is displayed on the LCD when this function is enabled.

3.9 Period Indicators

Push **PERIOD** once to increment the period indicator. The LCD display will show the period directly below the time.

3.10 Timeout Period

An automatic timeout period of 1 minute is provided for "Time Outs" when the main timer is not running.

Push: **TIME OUT TIMER** to start the 1 minute timer. The LCD will show "TIME OUT = 1:00" and start to count down. When 1 minute has elapsed the internal beeper sounds, and the display returns to the current game time.

If you want to return to play before the Time Out Timer gets back to zero, push: **CLEAR** and the console will return to play mode.

3.11 Penalty Time Control

To set a penalty time, Push **PEN 1** or **PEN 2** followed by the time as in the following example for a 3 minute penalty for player no. 25.

Push: **PEN 1** **3** **0** **0** **ENTER** **2** **5** **ENTER** **.**

To enable the penalty timers push **PEN ON**. This will start the penalty timer.

3.12 Time Outs Left

To enter or correct time outs left: Push Home or Guest **T.O.L.** followed by the desired number, then **ENTER**. To clear time outs left: Push Home or Guest

T.O.L., then **CLEAR**.

3.13 Shots On Goal

To add 1 to shots on goal: Push Home or Guest **+1 S.O.G.**.

To correct shots on goal: Push Home or Guest **SHOTS ON GOAL** and the correct number, then **ENTER**.

To clear shots on goal: Push Home or Guest **SHOTS ON GOAL**, then **CLEAR**.

3.14 Interval Timer

To use the interval timer, first, set the time using steps from section 3.6.

To set the interval timer, Push: **INT TMR**

The LCD display will read as follows:

INTERVAL TIME =

Select the time period by pushing the number keys as desired, and **ENTER**.

As the time counts down, the horn will sound at the selected intervals.

4. MAINTENANCE AND TROUBLESHOOTING

4.1 Introduction

This section gives maintenance and troubleshooting information. Included are troubleshooting guides for typical scoreboard malfunctions. If the cause of a problem cannot be determined, please contact the customer service department.

4.2 Test Equipment

A simple analog or digital voltmeter will be sufficient for all user repairable problems. Printed circuit boards requiring troubleshooting should be returned to the factory.

WARNING

120 VAC wires are exposed whenever the cover over the controller assembly is removed from the scoreboard. Use extreme caution during troubleshooting or repair. To avoid possible damage always remove power before removing the cover or replacing assemblies.

4.3 Troubleshooting

Whenever possible, follow the troubleshooting guides prior to contacting the customer service department. If a problem not described in the guides exists, contact the customer service department immediately. Refer to the diagrams provided for assistance in troubleshooting scoreboard malfunctions.

4.4 Troubleshooting Guides

(A) Scoreboard doesn't light and console doesn't work

- (a) Check that the main power switch is turned on.
- (b) Replace any defective or blown fuses.
- (c) Check the power connections and voltages at the scoreboard.
- (d) Contact the customer service department.

(B) Scoreboard digits don't light, but the console works

- (a) With the main power switch "off"; remove the cover over the controller assembly.
- (b) Check all connections.
- (c) Turn the main power on.
- (d) If the scoreboard still doesn't light, check the transformer voltage going to the receiver PCB (printed circuit board) assembly (blue wires) using a voltmeter set on the 12 VAC or higher scale.

If the voltage is less than 8 VAC contact the customer service department.

If the voltage is between 8-12 VAC see the replacement parts list for a receiver PCB assembly, and contact the customer service department.

(C) The scoreboard digits light but the console doesn't work

- (a) Check for continuity between the scoreboard and the junction box.
- (b) If an open circuit is found, the problem is either the cable or a cable connection.
- (c) If the continuity test checks good, check the voltage between the green wire and the white wire in the junction box, using a voltmeter set on the 12 VAC or higher scale.

If the voltage is 0 VAC see the controller parts list for a transformer assembly.

If the voltage is less than 8 VAC consult the controller wiring diagram for instructions on long cable compensation.

If the voltage is between 8 VAC and 12 VAC contact the customer service department.

(D) The scoreboard digits light, the console works, but there is no control of the scoreboard.

- (a) Check the voltage between the black and red wires in the junction box with a voltmeter set on the 3 VDC or higher scale. The voltage should read somewhere between 2-3 VDC when the console is working properly.
- (b) If the voltage is 0 VDC contact the customer service department for assistance.
- (c) If the voltage is correct, (2-3 VDC) check that this reading also appears at the scoreboard.
- (d) If the correct voltage also appears at the scoreboard, see the replacement parts list for a receiver PCB assembly.

(E) The scoreboard works, but some lights stay on all the time

- (a) With the main power "OFF", switch the plug from the bad digit with the plug for a known good digit.

EXAMPLE: Plug "C" into "D" and "D" into "C" locations.

(b) Turn the power back on. If the same lamps remain lit all the time, the problem is a shorted lamp socket. If the lamps on a different digit now stay lit all the time, the problem is on the driver PCB assembly. See the replacement parts list for the proper replacement part.

(F) The scoreboard works, but some lights do not come on.

(a) Check for burned out lamps.

IMPORTANT !!!

In this scoreboard the 120 volt line is on the lamp socket all the time, and the common is switched to turn the lamps on and off. For this reason, to avoid damage to the equipment or personal injury, it is important to turn the main power off when changing the lamps.

(b) Check for a broken wire or bad connection on the 12 pin connector.

(c) See the replacement parts list for the proper replacement driver board.

5. REPLACEMENT PARTS LIST

5.1 Scoreboard Display Parts




figure 1

DISPLAY ASSEMBLY

REPLACEMENT PARTS LIST (MP-3524 Hockey)

fig. & index	MFG PART NUMBER	DESCRIPTION	REF DES	VENDOR PART #
1-	000000	Display Set,		000000
1-1	850029	Lamp, 25W/130V Inside Frosted		25A19 IF
1-2	850022	Lamp, 15W/130V Clear		15A15CL
1-2A	850030	Lamp, 25W/130V Clear		25A19 GR CL
1-3	850032	Lamp, 40 W., 130 V., Clear		40A19 CL
1-4	122308	Controller Assembly, W/12-3P Drivers *****SEE DETAIL FIGURE 2*****	A2	122308
1-5	122325	Load Center, 16CKT, 125 AMP		QO16L-125RB
1-6	700900	Circuit Breaker, 15A 120V (10 ea)		QO-115
1-7	EL044100	Resistor, 2 OHM 30 WATT Wire Wound		HL-24-09Z
1-8	117456	Screen, (Home & Guest Score)		117456
1-9	119367	Screen, (Player Number & Shots)		119366
1-10	000000	Screen, (Penalty time minutes & T.O.L.)		000000
1-11	702623	Connector, 2C Fem. AB (HORN)	J5	S3302AB
	SU4450 HB005500 HB002300	Control Console, with battery backup & 27256 EPROM Slipsheet Pair Transmitter PCB Assembly *** PROGRAM POWER.V00 ***	A1	SU4450 HB005500 HB002300
	SW005100 702785 EL053000 HB002400 WH009100 122763	Toggle Switch, Connector, 5 Pin Male Cable LCD Display, 2 Line 20 Character Keyboard Assembly, Ribbon Cable Assembly, 14C 8" Enclosure,	S1 P1	SW005100 RM12BPG5P HB002400 WH009100
	151002 702786 150508	Press Box Junction Box, Connector, 5 Pin Female Cable, MP-40 Control	J1	151002 RM12BRD5S YR21233
	118044	Horn, #55 Trumpet		118044

5.2 Scoreboard Controller Assembly Parts





figure 2

CONTROLLER ASSEMBLY

REPLACEMENT PARTS LIST (MP-3524) Controller Assembly				
fig. & index	MFG PART NUMBER	DESCRIPTION	REF DES	VENDOR PART #
2-	122308X	Controller Assembly	A2	122308X
2-1	119323	Receiver PCB Assy, with 80C32 Micro-P *** PROGRAM CTRPWR.V00 ***	A3	119323
2-2	118922	Driver PCB Assembly, 3 Position	A4-A15	118922
2-3	118522	Transient Suppressor PCB Assembly	A8	118522
2-4	701137	Terminal Block, 7C	TB1&2	670-7
2-5	703719	Transformer, 8V/18V	T1/T2	CS-697
2-6	700520	Varistor,		ERZ-C20DK201U
2-7	705723	Spacer, P.C. Board		LCBS-6-01


6. DIAGRAMS

6.1 Control Console Keyboard and Slipsheet Layout




CONSOLE KEYBOARD

6.2 Scoreboard System Layout




SYSTEM LAYOUT

6.3 Single Junction Box Wiring



SINGLE JUNCTION BOX WIRING


6.4 Controller Assembly Wiring



IF DATA CABLE LENGTH EXCEEDS
WHITE WIRE OVER 1 POSITION ON
CONNECTING IT TO THREE TERM



CONTROLLER ASSEMBLY

6.5 Power Wiring Diagram



POWER WIRING



6.6 Microprocessor 4 X 7 Lamp Pattern (8 Bit)



		NUMERALS									
		0	1	2	3	4	5	6	7	8	9
BIT NUMBERS	1	0	.	2	3	.	5	6	7	8	9
	2	0	1	2	3	4	.	.	7	8	9
	3	0	1	.	3	4	5	6	7	8	9
	4	0	.	2	3	.	5	6	.	8	9
	5	0	.	2	.	.	.	6	.	8	.
	6	0	.	.	.	4	5	6	.	8	9
	7	.	.	2	3	4	5	6	.	8	9
	8	0	1	2	3	4	5	6	7	8	9

MICROPROCESSOR 4 X 7 (8 BIT) LAMP PATTERN

6.7 Figuregram Wiring




8 BIT FIGUREGRAM WIRING

6.8 Jumper Location on 3 Position System

All of the 3 position drivers and receivers are identical except for the jumper on each board. Make sure the jumpers are set for the model of scoreboard you are installing them into.


- (A) On the receiver board (refer to figure); Jumper pins 2 & 3 for models MP-3385, MP-3312, MP-3529, and MP-3549. Jumper pins 1 & 2 for all other models.
- (B) On the driver board (refer to figure); Jumper pins 1 & 2 for use of a horn. Jumper pins 2 & 3 for all others.



JUMPER LOCATION


6.9 Triac Placement

The triac is the switch that controls the figuregram lamps. The triacs for any given figuregram are adjacent to the twelve pin connector on the driver board that controls that figuregram. Shown below is the triac placement and bit designation relative to the figuregram bit pattern.




MP TRIAC PLACEMENT

6.10 Installation Drawing




INSTALLATION DIAGRAM

6.10 Installation Drawing (cont.)



INSTALLATION DIAGRAM

6.10 Installation Drawing (cont.)



INSTALLATION DIAGRAM