Operating Instructions & Service Manual

Baseball Scoreboard
Model MP-3353R With MP-3000R Control

EFFECTIVE S.N. 16,910 September 22, 2000

TABLE OF CONTENTS

		PAGE
1.	**GENERAL INFORMATION**	**3**
1.1	DESCRIPTION	
1.2	IDENTIFICATION	
1.3	DAMAGE	
1.4	DAMAGE CLAIM PROCEDURE	
2.	**INSTALLATION**	**4**
2.1	GENERAL INFORMATION	
2.2	INSPECTION	
2.3	INSTALLATION	
2.4	ELECTRICAL CONNECTIONS	
3.	**CONTROL CONSOLE OPERATION**	**5**
3.1	SCOREBOARD POWER	
3.2	CONSOLE DISPLAY	
3.3	CONSOLE POWER	
3.4	INITIALIZING SCOREBOARD	
3.5	TIME SETTING AND CONTROL	
3.6	TEAM SCORES	
3.7	INNING	
3.8	BALL, STRIKE, AND OUT	
3.9	HIT & ERROR	
3.10	DIMMER	
4.	**MAINTENANCE AND TROUBLESHOOTING**	**7**
4.1	INTRODUCTION	
4.2	TEST EQUIPMENT	
4.3	TROUBLESHOOTING	
4.4	TROUBLESHOOTING GUIDE	
5.	**REPLACEMENT PARTS LIST**	**10**
5.1	SCOREBOARD DISPLAY PARTS	
5.2	SCOREBOARD CONTROLLER ASSEMBLY PARTS	
6.	**DIAGRAMS**	**13**
6.1	CONTROL CONSOLE KEYBOARD AND SLIPSHEET LAYOUT	
6.2	SCOREBOARD SYSTEM LAYOUT	
6.3	POWER WIRING	
6.4	CONTROLLER ASSEMBLY WIRING	
6.5	MICROPROCESSOR 4X 7 LAMP PATTERN (8 BIT) (A-12497)	
6.6	FIGUREGRAM WIRING DIAGRAM	
6.7	JUMPER LOCATION ON 3 POSITION SYSTEM	
6.8	TRIAC PLACEMENT DIAGRAM	
6.9	INSTALLATION DRAWINGS	

1. GENERAL INFORMATION

1.1 Description

Your All American Scoreboard has been carefully inspected and tested before leaving the factory. It is possible, however, that components may be loosened or forced out of adjustment in transit. If this occurs, follow the troubleshooting guide (section 4). If equipment then fails to operate, contact immediately:

ALL AMERICAN Service Department
EVERBRITE Corporation
P.O. Box 100
Pardeeville, WI 53954
Telephone: (608) 429-2121
Toll Free: 800-356-8146

Parts being returned for repair are to be sent to:

ALL AMERICAN Service Department
EVERBRITE Corporation
401 S. Main Street
Pardeeville, WI 53954
E-mail score@everbrite.com

NOTE

If you need to send parts in for repair, please call the ALL AMERICAN service department for a returned goods authorization (RGA) number.

1.2 Identification

All American uses a 5 digit serial number for scoreboard identification. The serial number tags are located on the back of the control console and the lower right-hand corner on the face of the scoreboard display. When contacting the factory for assistance it is important that the model number and serial number are known.

1.3 Damage

Upon receipt, check for visible damage. If this occurs, or if damage is found after shipment has been accepted, follow the damage claim procedure.

1.4 Damage Claim Procedure

An instruction sheet is enclosed advising the consignee in case of damage in transit. If damage is noted at the time of delivery, consignee must obtain an 'Inspection of Bad Order' from the delivering carrier. In order to process your claim, this must be properly filled out with a complete statement of all damage and it must be signed by the carrier.

If damage is discovered after delivery, you should call the delivery company. Have them make out a Concealed Damage Report. Fifteen days after delivery are allowed, so this should be done PROMPTLY or it is impossible to process this claim.

Advise EVERBRITE corporation of necessary replacement parts or repairs.

Consignee will be invoiced and then should file a claim with the carrier to recover charges. TO FILE YOUR CLAIM FOLLOW THIS PROCEDURE:

(A) Cost of replacement parts or repair charges are invoiced to the carrier by the consignee.
(B) The following documents, properly filled out, plus invoice are forwarded to the trucking company in support of your claim:

(a) Original bill of lading
(b) Original paid freight bill
(c) Certified copy of original invoice
(d) Standard form for presentation of loss and damage claim properly filled out.

2. INSTALLATION

2.1 General Information

Shipping papers accompany each scoreboard. Check carefully to see that you receive the following:

1 ea Baseball Display (2 cartons)
1 ea Control Console
1 ea Service Manual
1 ea Mounting Hardware Package
1 ea Power Adaptor

2.2 Inspection

Tighten all screws and fittings that may have loosened in shipment.

2.3 Installation

Select the location best suited for visibility by the majority of spectators. Preferred position is facing east or north to avoid direct sunlight on the face of the scoreboard, if day games are played. For permanent mounting to uprights, see the enclosed installation drawing in Section 6.

2.4 Electrical Connections

This scoreboard requires: With 15 Watt lamps; One 30 AMP AC circuit or two 15 AMP AC circuits, With 30 Watt lamps; One 60 AMP AC circuit or two 30 AMP AC circuits, for the exclusive use of the scoreboard. The individual enclosure sections of the display may have a 3-4” diameterhole in the sides for the cables to run from the lamp banks to the controller assembly.

You must pull these cables through to the controller assembly and plug them in to the correct driver board before the lampbanks will operate correctly.

IMPORTANT!!!

To protect the control from damage, it is advisable that you disconnect the control and store in a dry secure area when not in use.

NOTE

This equipment is **ETL** (Electronics Testing Laboratories) **CSA** and **NRTL** approved and complies with the requirements in part 15 of the FCC rules for a class A computing device. Operation of this equipment in a residential area may cause unacceptable interference to radio and television reception, requiring the operator to take whatever steps are necessary to correct the interference.

3. CONTROL CONSOLE OPERATION

3.1 Scoreboard Power

Turn on the branch circuits to the scoreboard. The Home and Guest scores will show "0".

3.2 Console Display

The 2 line by 20 character Liquid Crystal Display module displays the scoreboard information entered from the keyboard. The following information is displayed continuously: Time, Home and Guest scores, Inning, Ball, Strike, Out, and Auto Horn Enable.

3.3 Console Power

Plug the control console cable into the Press Box junction box.

Push **ON/OFF** once to turn the console on.

Push **ON/OFF** a second time to shut the console off.

When first turned on; the console display should show as follows:

SCOREBOARD CONTROL
1991 VERSION 3.3

3.4 Initializing Scoreboard

Enter the two digit code (**73**) shown in the lower left corner of the keyboard as in the following example:

Push **CODE** **7** **3** **ENTER** .

When the proper code has been entered, the console display will show as follows:

0	:00	0
0 H		0

3.5 Time Setting and Control

To set an 8 minute period, Push: **SET** **8** **0** **0** **ENTER** .

Any time up to 99:59 may be preset in a similar manner.

The **UP/DN** key determines the timer mode. When in the UP mode an arrow up symbol is displayed next to the time on the LCD display. If in the DOWN mode there is no arrow displayed.

Switching the time toggle switch to the IN and OUT position, starts and stops the timer.

Push **RESET** , with the timer stopped, to return the timer to the previously set value.

3.6 Team Scores

The Home and Guest Scores can be changed in three different ways.

(A) To add 1 to the existing score: Push **+1** .

(B) To directly enter or correct a score: Push Home or Guest **SCORE** followed by the desired number, then **ENTER** .

Example: Present Home Score is 15. Change the score from 15 to 23.

Push: Home **SCORE** **2** **3** **ENTER** .

(C) To clear the score: Push **SCORE** **CLEAR** .

3.7 Inning

Entry to the above function is made in the same manner as direct entry for Team Scores.

3.8 Ball, Strike, and Out

Push **BALL** , **STRIKE** , or **OUT** , once for each increment of the appropriate indicator.

3.9 Hit & Error

Push **HIT** , or **ERROR** to increment the appropriate indicator.

3.10 Dimmer

Push **DIMMER** to dim the lamps during night use.

WARNING

120 VAC wires are exposed whenever the cover over the controller assembly is removed from the scoreboard. Use extreme caution during troubleshooting or repair. To avoid possible damage to equipment or personal injury, always turn off the main power before removing the cover or replacing assemblies, or replacing lamps.

4. MAINTENANCE AND TROUBLESHOOTING

4.1 Introduction

This section gives maintenance and troubleshooting information. Included are troubleshooting guides for typical scoreboard malfunctions. If the cause of a problem cannot be determined, please contact the Customer Service Department.

4.2 Test Equipment

A simple analog or digital voltmeter will be sufficient for all user repairable problems. Printed circuit boards requiring troubleshooting should be returned to the factory.

4.3 Troubleshooting

Whenever possible, follow the troubleshooting guides prior to contacting the customer service department. If a problem not described in the guides exists, contact the customer service department immediately. Refer to the diagrams provided for assistance in troubleshooting scoreboard malfunctions.

4.4 Troubleshooting Guides

(A) Scoreboard doesn't light and console doesn't work:

(a) Check that the main power switch is turned on.
(b) Replace any defective or blown fuses.
(c) Check the power connections and voltages at the scoreboard.
(d) Contact the Customer Service Department.

(B) Scoreboard digits don't light but the console works:

(a) With the main power switch "OFF"; remove the cover over the controller assembly.
(b) Check all connections.
(c) Turn the main power "ON".
(d) If the scoreboard still doesn't light, check the transformer voltage going to the receiver PCB (printed circuit board) assembly (blue wires) using a voltmeter set on the 12 VAC or higher scale.

If the voltage is less than 8 VAC contact the Customer Service Department.

If the voltage is between 8-12 VAC see the replacement parts list for a receiver PCB assembly, and contact the Customer Service Department.

(C) The scoreboard digits light but the console doesn't work:

(a) Check for continuity between the scoreboard and the junction box.
(b) If an open circuit is found, the problem is either the cable or a cable connection.
(c) If the continuity test checks good, check the voltage between the green wire and the white wire in the junction box, using a voltmeter set on the 12 VAC or higher scale.

If the voltage is 0 VAC see the controller parts list for a transformer assembly.

If the voltage is less than 8 VAC consult the controller wiring diagram for instructions on long cable compensation.

If the voltage is between 8 VAC and 12 VAC contact the Customer Service Department.

(D) The scoreboard digits light, the console works but there is no control of the scoreboard:

(a) Check the voltage between the black and red wires in the junction box with a voltmeter set on the 3 VDC or higher scale. The voltage should read somewhere between 2-3 VDC when the console is working properly.
(b) If the voltage is 0 VDC contact the Customer Service Department for assistance.
(c) If the voltage is correct, (2-3 VDC) check that this reading also appears at the scoreboard.
(d) If the correct voltage also appears at the scoreboard, see the replacement parts list for a receiver PCB assembly.

(E) The scoreboard works, but some lights stay on all the time:

(a) With the main power "OFF", switch the plug from the bad digit with the plug for a known good digit. EXAMPLE: Plug "C" into "D" and "D" into "C" locations.
(b) Turn the power back on. If the same lamps remain lit all the time, the problem is a shorted lamp socket. If the lamps on a different digit now stay lit all the time, the problem is on the driver PCB assembly. See the replacement parts list for the proper replacement part.

(F) The scoreboard works but some lights do not come on:

(a) Check for burned out lamps.
(b) Check for a broken wire or bad connection on the 12 pin connector.
(c) See the replacement parts list for the proper replacement driver board.

IMPORTANT !!!

In this scoreboard the 120 volt line is on the lamp socket all the time, and the common is switched to turn the lamps on and off. For this reason, to avoid damage to the equipment or personal injury, it is important to turn the main power off when changing the lamps.

5. REPLACEMENT PARTS

5.1 Scoreboard Display Parts



figure 1

DISPLAY ASSEMBLY

REPLACEMENT PARTS LIST (MP-3353R)

fig.& index	MFG PART NUMBER	DESCRIPTION	REF DES	VENDOR PART #
1-	151128	Display Set,		151128
1-1	850022	Lamp, 15W/130V Clear(Scores & Inning)		15A15CL
1-1A	930677	Lamp, 30W/130V I.F. (Scores & Inning)		30A15IF
1-2	850030	Lamp, 25W/130V Clear (Ball,Strike,Out)		25A19 GR CL
1-3	850032	Lamp, 40W/130V Clear (Hit & Error)		40A19 CL
1-4	151208	Controller Assembly, W/4-3P Drivers *****SEE DETAIL FIGURE 2*****	A2	151208
1-5	SU00038	Fuse Box,		SU00038
1-5A	121880	Fuse, 15A. 250V.	F1-F2	ABC-15 (3AG)
1-6	EL00474P	Antennae		EL00474P
1-6A	WI00018P	Antennae Cable, 2.4 GHZ		WI00018P
1-7	150660	Rain Shield		150660
1-8	150668	Service Door		150668
1-9	705923	Screen, INNING		705923
1-10	705922	Screen, HOME & GUEST SCORES		705922
1-11	EL044100	Resistor, 2 OHM 30 WATT Wire Wound		HL-24-09Z
	150021	Control Console, 3000 Radio		150021
	HB005500	Slipsheet Pair		HB005500
	150031	Transmitter PCB Assembly ***** PROGRAM MP3V38W *****	A1	150031
	SW005100	Toggle Switch,	S1	SW005100
	EL00479P	Tranceiver, 2.4 GHZ Zeus		EL00475P
	EL00473P	Antenna, Internal		EL00473P
	EL053000	LCD Display, 2 Line 20 Character		
	HB002400	Keyboard Assembly,		HB002400
	WH009100	Ribbon Cable Assembly, 14C 8”		WH009100
	122763	Enclosure,		
	EL00478P	Power Adaptor, 9 VDC 300 mA		EL00478P

5.2 Scoreboard Controller Assembly Parts



figure 2

CONTROLLER ASSEMBLY

REPLACEMENT PARTS LIST (MP-3353R) Controller Assembly				
fig.& index	MFG PART NUMBER	DESCRIPTION	REF DES	VENDOR PART #
2-	151208	Controller Assembly	A2	151208
2-1	150040	Receiver PCB Assembly ***** PROGRAM 3PCNT19W *****	A3	150040
2-2	118922	Driver PCB Assembly, 3 Position	A4-A7	118922
2-3	EL00479P	Tranceiver, 2.4 GHZ Zeus		EL00479P
2-4	701137	Terminal Block, 7C	TB1&2	670-7
2-5	703719	Transformer, 8V/18V	T1/T2	CS-697
2-6	HB005600	Cover		HB005600
2-7	705723	Spacer, P.C.Board		LCBS-6-01

6. DIAGRAMS

6.1 Control Console Keyboard and Slipsheet Layout



BASEBALL



SOCCER

CONSOLE KEYBOARD

6.2 Scoreboard System Layout



SYSTEM LAYOUT

6.3 Power Wiring



POWER WIRING

6.4 Controller Assembly Wiring



CONTROLLER ASSEMBLY

6.5 Microprocesor 4 X 7 Lamp Pattern (8 Bit)





NUMERALS

BIT NUMBERS	0	1	2	3	4	5	6	7	8	9
1	0	.	2	3	.	5	6	7	8	9
2	0	1	2	3	4	.	.	7	8	9
3	0	1	.	3	4	5	6	7	8	9
4	0	.	2	3	.	5	6	.	8	9
5	0	.	2	.	.	.	6	.	8	.
6	0	.	.	.	4	5	6	.	8	9
7	.	.	2	3	4	5	6	.	8	9
8	0	1	2	3	4	5	6	7	8	9

MICROPROCESSOR 4 X 7 (8 BIT) LAMP PATTERN

6.6 Figuregram Wiring



8 BIT FIGUREGRAM WIRING

6.7 Jumper Location on 3 Position System

All of the 3 position drivers and receivers are identical except for the jumper on each board. Make sure the jumpers are set for the model of scoreboard you are installing them into.

(A) On the receiver board (refer to figure 11); Jumper pins 2 & 3 for models MP-3385, MP-3312, MP-3529, and MP-3549. Jumper pins 1 & 2 for all other models.

(B) On the driver board (refer to figure 10); Jumper pins 1 & 2 for use of a horn. Jumper pins 2 & 3 for all others.



JUMPER LOCATION

6.8 Triac Placement

The triac is the switch that controls the figuregram lamps. The triacs for any given figuregram are adjacent to the twelve pin connector on the driver board that controls that figuregram. Shown below is the triac placement and bit designation relative to the figuregram bit pattern.



MP TRIAC PLACEMENT

6.9 Installation Drawing



INSTALLATION DRAWING

6.9 Installation Drawing



INSTALLATION DRAWING