THERE WILL BE A CONNECTOR BRACKET AND LATCHES ON THIS SIDE AS WELL!!!

BOTH SIDES OF EVERY TABLE ON ORDER WILL NEED ALL REQUIRED BRACKETS/LATCHES.

PLACE CONNECTOR BRACKET INTO TABLE WHILE ASSEMBLING. SEE APPROPRIATE DWG. ADD BEFORE PLACING THE RIVETS IN THE TOP AND END CAP HOLES.

NOTE ORIENTATION (CUT OUT ON TOP) WHEN SETTING PAD ASSY IN.

THIS TABLE SHOWN WITHOUT THE TABLETOP FOR CLARIFICATION.

BOLTS WILL FIT INTO KEYED PUNCHES ON TABLES. THE NUTS WILL NEED TO BE SPACED CORRECTLY BEFORE.

089-00011
(WHEN VIEWING FRONT FACE PANEL)
1. MOUNT LATCH TO LEFT SIDE OF CHASSIS. (FOR EACH TABLE ON ORDER)
2. MOUNT RECEIVER TO RIGHT SIDE OF CHASSIS. (FOR EACH TABLE ON ORDER)

089-00008
(WHEN VIEWING FRONT FACE PANEL)
1. MOUNT LATCH TO LEFT SIDE OF CHASSIS. (FOR EACH TABLE ON ORDER)
2. MOUNT RECEIVER TO RIGHT SIDE OF CHASSIS. (FOR EACH TABLE ON ORDER)

DETAIL A
SCALE 1 : 4

VIEW SHOWING CHASSIS BEING LATCHED TOGETHER FROM FRONT.

VIEW SHOWING HOW THE LATCH WILL GET CONNECTED TO CHASSIS. USE DAT HOLES IN CONNECTOR BRACKETS AND FILL USING (8) 10-24 X .75 PH TR HD SCREWS. LATCHES WILL NOT BE ENGAGED AT THIS POINT AND WILL BE IN TO PIECES. REFER TO THIS NOTE AND ISO VIEW ABOVE TO LOCATE WHICH HALF GOES WHERE. (ADD (8) MORE SCREWS PER EXTRA TABLE.)

VIEW SHOWING HOW LATCH WILL GET CONNECTED TO TABLES. USE THE TEMPLATE FOR EXACT LOCATION. DRILL A PILOT HOLE FOR A #6 AND FILL USING (4) #8 X .5 WOOD SCREWS SCREWS. (ADD (4) MORE SCREWS PER EXTRA TABLE.

SPACER/BUMPER
(WHEN VIEWING FRONT FACE PANEL)
1. MOUNT TO LEFT SIDE OF TABLETOP (FOR EACH TABLE ON ORDER)

DETAIL B
SCALE 1 : 5

CONNECTOR, PAD ASSY
1 REQUIRED

FSTNR,DRAW LATCH,1-9/16"T HNDL - 089-00008
2 REQUIRED
ALL LATCHES TO BE MOUNTED ON LEFT SIDE (WHEN VIEWING FRONT FACE PANEL)
ALL RECEIVERS TO BE MOUNTED RIGHT SIDE (WHEN VIEWING FRONT FACE PANEL)

FSTNR,DRAW LATCH,4-3/16"T HNDL - 089-00011
1 REQUIRED
ALL LATCHES TO BE MOUNTED ON LEFT SIDE (WHEN VIEWING FRONT FACE PANEL)
ALL RECEIVERS TO BE MOUNTED RIGHT SIDE (WHEN VIEWING FRONT FACE PANEL)

HDW,BUMPER,2.5"X.625"WX.625"H - 090-00009
1 REQUIRED
ALL TO BE MOUNTED ON LEFT SIDE OF TABLETOP (WHEN VIEWING FRONT FACE PANEL)

CONNECTOR, BRACKET
2 REQUIRED
(MOUNT ONE ON EACH SIDE OF EACH TABLE BEING CONNECTED)

IMPORTANT NOTE:
ALL ATTACHMENT OF EXTRA CONNECTING PARTS **MUST BE DONE** WHILE BUILDING THE TABLES NEEDED FOR THE ORDER. NOT TO JUST USE STOCK TABLES. THIS IS TO ALLOW FOR EASIER ATTACHMENT OF BRACKETS AND LATCHES.

IMPORTANT NOTE:
THIS SAME METHOD OF ATTACHMENT AND PART QUANTITIES WILL WORK FOR ALL TABLE SIZES ALIKE. THERE WILL BE A KIT FOR EVERY SCORETABLE ORDERED FOR THE CONNECTION TABLE ORDER.

OVERALL DETAILS

048-00029 | SHEET 1 OF 2

Everbrite

FAB ASSY,SCTBL CONNECTOR

T.A. | 12/3/2012 | 1:10 | 048-00029 | C

FILE LOCATION: G:\SLDRELDWG\048 DWGS\048-00029 - FAB ASSY,SCTBL CONNECTOR\048-00029.SLDDWG