


Scoreboard Type: 400

# 8420ECTN ALL AMBER Controller Plate



Power Supply Outputs (Full Brightness & Full Digits):

P1.1 ≈ 3.6A	P1.2 ≈ 3.5A	P1.3 ≈ 2.4A	P1.4 ≈ 2.5A
P2.1 ≈ 2.4A	P2.2 ≈ 2.50A	P2.3 ≈ 3.6A	P2.4 ≈ 3.6A
P3.1 ≈ 4.9A	P3.2 ≈ 4.9A	P3.3 ≈ 2.45A	P3.4 ≈ 4.9A
P4.1 ≈ 4.9A	P4.2 ≈ 4.9A	P4.3 ≈ 4.9A	P3.4 ≈ 4.9

"C" refers to controller board output. If Indicators are used, C4 data will go to the Indicator Driver Board and then to the digit(s).