

ALL AMERICAN

SCOREBOARDS

TM



For item Numbers:

ST2PLFL & ST2PLBCH

ST3PLFL & ST3PLBCH

ST4PLFL & ST4PLBCH

ST5PLFL & ST5PLBCH

ALL AMERICAN INDOOR

SCORETABLES

INSTALLATION AND OPERATIONS MANUAL

TABLE OF CONTENTS

Table of Contents

1.0 General Information	4
1.1 Description	4
1.2 Damage.....	4
1.3 Damage Claim Procedure.....	4
2.0 Installation	5
2.1 General Information	5
2.2 Uncrate Scoretable	5
2.3 Inspection	5
2.4 Setup.....	6
2.5 Wheel Locking	7
2.6 Electrical Connections	7
2.7 P18 Possession Indicator Instructions.....	7
3.0 Safety	8
4.0 Technical Support	9
4.1 Customer Service	9
4.2 Contact Information.....	9

Manual Overview

This manual is intended for the use of the All American Scoreboard owners and users. Read this manual carefully before starting the equipment.

This manual contains important information for operation and maintenance of the equipment. It also contains important instructions to prevent accidents, personal injury and/or serious damage prior to or during operation of the equipment.

Familiarize yourself thoroughly with the function and operation of this equipment and strictly observe the directions given. If you have any questions or need further details on specific aspects related to the AAS system, please do not hesitate to contact us.

In this manual you will find three levels of flagged notes or warnings.



WARNING! THE WARNING MESSAGE IS USED WHEN A LIFE THREATENING SITUATION MAY ARISE OR PERSONAL INJURY CAN RESULT.



CAUTION! The caution message is used when there is a danger of damage to the equipment, materials, or other important information; such as Warranty issues.

NOTE: The Note message is used to give operational information and useful tips.

1. GENERAL INFORMATION

1.1 Description

Your All American Scoring Table has been carefully inspected and tested before leaving the factory. It is possible, however, that components may be loosened or forced out of adjustment in transit. If this occurs, follow the troubleshooting guide (section 4). If equipment then fails to operate, contact immediately:

Telephone: (608) 429-2121

Toll Free: 800-356-8146

NOTE: If you need to send parts in for repair, please call the ALL AMERICAN service department for a returned goods authorization (RGA) number.

1.2 Damage

Upon receipt, check for visible damage. If this occurs, or if damage is found after shipment has been accepted, follow the damage claim procedure.

1.3 Damage Claim Procedure

An instruction sheet is enclosed advising the consignee in case of damage in transit. If damage is noted at the time of delivery, consignee must obtain an 'Inspection of Bad Order' from the delivering carrier. In order to process your claim, this must be properly filled out with a complete statement of all damage and it must be signed by the carrier.

If damage is discovered after delivery, you should call the delivery company. Have them make out a Concealed Damage Report. Fifteen days after delivery are allowed, so this should be done promptly or it is impossible to process this claim.

Advise EVERBRITE corporation of necessary replacement parts or repairs.

Consignee will be invoiced and then should file a claim with the carrier to recover charges. To file your claim follow this procedure:

(A) Cost of replacement parts or repair charges are invoiced to the carrier by the consignee.

(B) The following documents, properly filled out, plus invoice are forwarded to the trucking company in support of your claim:

- (a) Original bill of lading
- (b) Original paid freight bill
- (c) Certified copy of original invoice
- (d) Standard form for presentation of loss and damage claim

2. INSTALLATION

2.1 General Information

Shipping papers accompany each scoring table. Check carefully to see that you receive everything ordered.

2.2 Uncrate Scoreboard

Carefully uncrate scoreboard.

2.3 Inspection

Tighten all screws, lamps, and fittings that may have loosened in shipment.

2.4 Setup

Scoreboard is shipped with the table top in the upright position (Figure 1). Carefully lower table top to a horizontal position (Figure 2).



Figure 1



Figure 2



CAUTION: The table is not ready to use until wings are unfolded to properly support the tabletop. See next page for details.

INSTALLATION

Referring to figures 2 and 3, while holding table top pull wings out until they are perpendicular to the back of the scoring table. The underside of the tabletop has rubber footings that each wing locks into (see figure 4).



Figure 2



Figure 3



Figure 4



ATTENTION

WINGS MUST BE PULLED OUT TO SUPPORT TABLE TOP.
DO NOT USE WITHOUT PROPERLY SECURING SUPPORT WINGS.

If not already installed, install the end pads on the table, making sure the left pad goes on the left side and the right pad goes on the right side. The pads will fit into the keyhole slots and drop down into position.

Position the table as needed and plug the power cord into an outlet.

2.5 Wheel Locking

The wheels on the scoreboard can be locked into position. This will help to keep the scoretable in place during operation. Before moving the scoretable, it is recommended to release all locks on the wheels.



Unlocked



Locked

2.6 Electrical Connections

The All American Scoretable comes equipped with a 6 Output power strip attached. This power strip is intended for use with an All American Scoreboards Console, a Possession Indicator and the illuminated ad panel on the front of the scoretable. Feed the cables from any desktop devices through the wire pass through holes at the top of the table.



This scoring table plugs into a 120 V. 20 AMP AC outlet.

2.7 Optional Free Standing Padded Possession Indicator



To operate the LED Possession Indicator, flip the switch on the back of the indicator towards the direction of the possession arrow that should be lit. Move switch to the center position to turn indicators off.



WARNING! OPERATION OF THE UNIT WITH THE ELECTRICAL EXPOSED IS DANGEROUS. BE SURE ALL TOOLS AND ANY OTHER MATERIALS ARE REMOVED FROM THE UNIT, AND ALL ACCESS COVERS ARE REPLACED AND CLOSED BEFORE POWER IS TURNED ON.

NOTE: For Advanced Trouble Shooting, Service Manuals and Replacement Part Information go to www.allamericanscoreboards.com.

3.0 Safety Information

The owner of the All American Scoreboard (AAS) is responsible for safe operation and repair. He therefore is obliged to familiarize operating personnel with the contents of this manual and make them aware of all possible hazards.

NOTE: When using this equipment, always follow the manufacturer's instructions for safe operation. In case of emergency, please telephone Technical Support or a qualified service technician.

Do not operate the sign until it is completely assembled and installed per the instructions supplied by AAS.

AAS recommends that your main power be installed by a licensed electrician in accordance with the local building and electrical codes.

All equipment must be grounded in accordance with the local building and electrical codes. AAS recommends Earth Link Ground.

If any part of the Scoreboard equipment is malfunctioning or has been damaged, cease operation and consult with AAS Technical Support or qualified service technician before further use.

Use only AAS specified or recommended replacements parts.



WARNING! USE A LOCK OUT/TAG OUT ON CIRCUIT BREAKERS OR "POWER ON/OFF" SWITCHES WHEN PERFORMING INSTALLATION, REPAIRS OR MAINTENANCE.

When performing repairs be mindful of the weather and work area conditions. Avoid the unit's exposure to the elements, water and debris, or anything that may be dangerous or cause damage to the equipment.



WARNING! OPERATION OF THE UNIT WITH THE ELECTRICAL CIRCUITRY EXPOSED IS DANGEROUS. BE SURE ALL TOOLS AND ANY OTHER MATERIALS ARE REMOVED FROM THE UNIT, AND ALL ACCESS COVERS ARE REPLACED AND CLOSED BEFORE POWER IS TURNED ON.



CAUTION: Use of solvent cleaners or a power washer on your Scoreboard may cause permanent damage.

© Copyright All American Scoreboards 2010

This is the exclusive property of All American Scoreboards® a division of Everbrite® LLC. Use of or duplication of this document in any manner without the expressed written consent of All American Scoreboards® is prohibited.

The information contained in this document is subject to change without notice and should not be construed as a commitment by All American Scoreboards®.

All American Scoreboards® assumes no responsibility for any errors that may appear in this document. Nor does it make expressed or implied warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

All American Scoreboards® shall not be liable for incidental or consequential damages in connection with, or arising out of the furnishing, performance, or use of this document and the program material, which it describes.

Trademarks Credits

All American Scoreboards® is a registered trademark of Everbrite® LLC.

Everbrite® is a registered trademark of AAS LLC.

4.0 Technical Support

4.1 Customer Service

Customer satisfaction is the top priority at AAS. Our skilled, experienced Account Management teams are dedicated to providing highly responsive service through all phases of our client's programs.

These teams are computer-linked to each of our manufacturing facilities to provide "on-line" updates on the status of customer orders. Furthermore, AAS's EDI capabilities allow electronic interchange to efficiently process customer orders.

4.2 Contact Information

All American Scoreboards
401 S. Main Street
Pardeeville, WI 53954
PHONE: 1 800-356-8146

www.allamericanscoreboards.com