



Turns display ON or OFF.



Switches between PROGRAM and QUICK MESSAGE modes.

Sends MESSAGE or PROGRAM selected on LCD to the sign.

Press then to perform a display test.

Resumes last PROGRAM sent after displaying a MESSAGE.



Use the keys to scroll through MESSAGES or PROGRAMS. When correct MESSAGE or PROGRAM is displayed on screen, press to display on sign.

On keypad, enter number of MESSAGE or PROGRAM then to quickly display MESSAGE or PROGRAM on screen.

Everbrite Message Center - PLAY MODE Help Sheet. Remove for EDIT MODE.

LA00262P



Turns display ON or OFF.



Switches between PROGRAM and QUICK MESSAGE modes.

Sends MESSAGE or PROGRAM selected on LCD to the sign.

Press then to perform a display test.

Resumes last PROGRAM sent after displaying a MESSAGE.



Use the keys to scroll through MESSAGES or PROGRAMS. When correct MESSAGE or PROGRAM is displayed on screen, press to display on sign.

On keypad, enter number of MESSAGE or PROGRAM then to quickly display MESSAGE or PROGRAM on screen.

Everbrite Message Center - PLAY MODE Help Sheet. Remove for EDIT MODE.

LA00262P


EMC REFERENCE SHEET

GETTING STARTED:

 (press and hold... wait for menu items) then  then 

NOTE: "LOADING PROGRAM" may appear on LCD. This happens when switching between sports and message mode.


PLAY MODE:


 When initially going into play mode, selects sign(s) to send messages - press  to confirm.


 Sends message or program to sign.

Quick message will remain until new message or program is sent.


Program will run in a continuous loop until new message or program is sent.

 Toggles between messages and programs.

 Scrolls left (up numerically) through messages and/or programs before sending to sign.

 Scrolls right (down numerically) through messages and/or programs before sending to sign.

  (or any message number) then  Jumps to message number for quick display.

 Change the brightness of the EMC. Enter values from  (dimmiest) to  (brightest), press 


 then  Toggle between auto brightness and manual brightness.

 Blanks display until another message or program is sent or until  is pressed.



 then  Runs through a display test. All LEDs light, then a single row goes through brightnesses

 Resumes a program after display blanks () or after a quick message is sent

Tip: To get a program to sync closer between multiple signs, press  then .

 Toggles between Edit and Play mode


EDIT MODE: (PASSWORD REQUIRED. Many keys in play mode operate the same as edit mode)

 When attempting to send a message to a sign(s), use to select EMC(s) - press  to confirm

Also selects programs or messages to add ("BLANK"*) or edit.

May also be used as an  in many functions.

 Sends message to sign for preview when editing messages or programs. This key will not send a program while in edit mode.

 Press this to insert time, temperature or date in the LINETEXT screen when editing a message

Press again to toggle between options. Auto Travel will occur if text is too long

NOTE: Text line must only have time and temp functions (no other text or characters).

 All of these blue keys are transition mode effects.

See page 11 in operators manual for more details.

NOTE: Message will Auto-Travel if text is too long to fit on sign. Auto-Travel can be over ridden


by simply selecting a different mode.

 then  will clear all messages. The console will confirm before clearing. All programs will also be cleared.

**The reverse side of this sheet can be inserted while in PLAY MODE.
For more information, please read the manual.**



EMC REFERENCE SHEET


GETTING STARTED:

 (press and hold... wait for menu items) then  then 

NOTE: "LOADING PROGRAM" may appear on LCD. This happens when switching between sports and message mode.


PLAY MODE:


 When initially going into play mode, selects sign(s) to send messages - press  to confirm.


 Sends message or program to sign.

Quick message will remain until new message or program is sent.





Program will run in a continuous loop until new message or program is sent.

 Toggles between messages and programs.

 Scrolls left (up numerically) through messages and/or programs before sending to sign.

 Scrolls right (down numerically) through messages and/or programs before sending to sign.

  (or any message number) then  Jumps to message number for quick display.

 Change the brightness of the EMC. Enter values from  (dimmiest) to  (brightest), press 


 then  Toggle between auto brightness and manual brightness.

 Blanks display until another message or program is sent or until  is pressed.



 then  Runs through a display test. All LEDs light, then a single row goes through brightnesses

 Resumes a program after display blanks () or after a quick message is sent

Tip: To get a program to sync closer between multiple signs, press  then .

 Toggles between Edit and Play mode


EDIT MODE: (PASSWORD REQUIRED. Many keys in play mode operate the same as edit mode)

 When attempting to send a message to a sign(s), use to select EMC(s) - press  to confirm

Also selects programs or messages to add ("BLANK"*) or edit.


May also be used as an  in many functions.

 Sends message to sign for preview when editing messages or programs. This key will not send a program while in edit mode.

 Press this to insert time, temperature or date in the LINETEXT screen when editing a message

Press again to toggle between options. Auto Travel will occur if text is too long

NOTE: Text line must only have time and temp functions (no other text or characters).

 All of these blue keys are transition mode effects.

See page 11 in operators manual for more details.

NOTE: Message will Auto-Travel if text is too long to fit on sign. Auto-Travel can be over ridden

by simply selecting a different mode.

 then  will clear all messages. The console will confirm before clearing. All programs will also be cleared.

**The reverse side of this sheet can be inserted while in PLAY MODE.
For more information, please read the manual.**