

OPERATING INSTRUCTIONS

for

MASCOT II PORTABLE SCOREBOARD

1. Plug AC line card into 120 VAC 60 HZ 5 AMP Electric service. Place power switch, on back of board, to ON position.

2. Timer Operation - (A) Descending

To reset timer merely set the two thumbwheel switches on the control console to desired time. With the time switch in the out position press the reset button momentarily, this will reset the timer to the desired time and then it may be switched to the in position when the period begins. The Buzzer will sound at the end of the period.

(B) Ascending

To reset the timer in this mode set the thumbwheel switches to :00. With the time switch in the out position press the reset button momentarily, this will reset the clock to :00. The time switch may then be switched to the on position when the period begins.

3. The set the score position merely set desired score on either HOME or GUEST dial knobs.
4. The Bonus lights are operated by switching on either HOME or GUEST Bonus switches to ON position.
5. The Period lights are operated by placing the period light indicator to desired period.
6. The Horn may be operated manually by the horn button on the back of the board.

NOTE: There are 4 spare lamps included inside the board. These may be obtained by removing the 5 top screws on the board and gently separating the board. These lamps are taped to the inside of the back.

DAMAGE CLAIM PROCEDURE

An instruction sheet is enclosed with each shipment advising the Consignee (location where board is shipped) what to do in case of damage in transit.

1) If damage is noted at time of delivery, Consignee must obtain an Inspection of Bad Order from the delivering carrier (truck driver or shipping agent). In order to process your claim, this must be properly filled out with a complete statement of all damage and signed by the carrier.

2) If damage is discovered after delivery, you (Consignee) should call the Express Agent (if rail shipment) or the delivering truck company (if truck shipment) and have him make out a Concealed Damage Report. Fifteen days after delivery are allowed so this should be done PROMPTLY or it is impossible to process this claim.

3) In either case, advise Consignor (ALL-AMERICAN) of necessary replacements, parts or repairs. Consignee will be invoiced and then should file claim with carrier to recover charges.

TO FILE YOUR CLAIM FOLLOW THIS PROCEDURE

- 1) Cost of replacement parts or repair charges are invoiced to the carrier by the Consignee.
- 2) The following documents, in addition to the invoice, are forwarded to the Truck Company or Express Agency in support of your claim.
 - a) Original bill of lading
 - b) Original paid freight bill
 - c) Certified copy or original invoice
 - d) Standard form for Presentation of Loss and damage claim properly filled out


ALL AMERICAN SCOREBOARDS are a product of:

GENERAL INDICATOR CORPORATION
Pardeeville, Wisconsin 53954

Telephone: Area 608/429-2121
Watts 800/356-8146

REVISIONS		DATE	APPROVAL
SYM.	DESCRIPTION		

PLUG IS RMP
 #206434-1 W/CABLE
 GRIP & BOOT ON LEFT
 YR 7667 CABLE.



FEDERHL 350N
 HORN

RELAY IS P/B
 KHP/712 12VDC


3	2	1	ITEM	PART NO.	DESCRIPTION	MATERIAL	MAT'L SPEC.
ASSEMBLY							
NEXT ASSEMBLY							
UNLESS OTHERWISE SPECIFIED							
TOLERANCE AFTER MACHINING				SURFACE FINISH NOT TO EXCEED			
PRACT. DEC. ANN.				DRAFT STOP			
MATERIAL				CHECKED			
FINISH				DESIGN ENGR.			
RELEASE				SCALE			
				DRAWING SIZE			
				B			
				DRAWING NO.			
				B 13046			
				SHEET			

LIST OF MATERIAL
 MHSOT II
 EXTERNAL
 HORN WIRING
 DINGHAM

GTIC
 general indicator
 corporation

NOTE:

28 Nov 67



PART NO.		DESCRIPTION	QUANTITY
1	1-480275-0	RELAY 10-5	1
2	1-480275-0	RELAY 10-5	1
3	1-480275-0	RELAY 10-5	1
4	1-480275-0	RELAY 10-5	1
5	1-480275-0	RELAY 10-5	1
6	1-480275-0	RELAY 10-5	1
7	1-480275-0	RELAY 10-5	1
8	1-480275-0	RELAY 10-5	1
9	1-480275-0	RELAY 10-5	1

LIST OF MATERIAL	
MASCOT II WIRING DIAGRAM	
General Indicator Corporation	
C-12809	

1-480275-0 (2)
 1-480275-0 (1)
 1-480275-0 (3)
 1-480275-0 (4)
 1-480275-0 (5)
 1-480275-0 (6)
 1-480275-0 (7)
 1-480275-0 (8)
 1-480275-0 (9)